

# imation



## IMATION SECURE SCAN



*User Manual  
Model ISSLTOA*

**System Requirements:**

Pentium 4 processor or better 512MB RAM minimum 10MB hard disk space minimum Two available USB-2 ports Color monitor - 1024X768 or greater native screen resolution required. 32 bit operating system ie. MicroSoft Windows 2000/XP or 64 bit operating system ie. Windows 7

**Software Installation:**

There are two installation versions of the software, one for 32 bit operating systems and another for 64 bit systems such as Windows 7. Please ensure that you download the proper file for your application. Follow the on screen instructions provided within the software installation package which can be downloaded from the link entitled "Imation Secure Scan Software" on: "<http://www.imation.com/en-us/Imation-Products/Tape-Cartridges--Accessories/Secure-Scan/>". Microsoft warnings regarding uncertified drivers can be ignored.

**Hardware Installation:**

The unit should be placed on a suitable work surface and in close proximity to the host computer to be used. After installation of the software, the two USB cables should be connected to two available USB-2 ports on the host computer.

**Safety:**

CAUTION: The Imation Secure Scan utilizes both an RFID scanner and a laser barcode scanner. Common sense safety practices should be employed when using this device. Do not look into the window when the device is actively scanning.

**Overview:**

Imation has been scanning cartridges for our customers since the introduction of the LTO1 cartridge in 2001 as part of our Technical Support function. The Imation Secure Scan device is the latest improvement in that process allowing customers to evaluate their LTO 1 through 5 cartridges continually at their convenience.

The Imation Secure Scan provides the LTO user with the capability to immediately determine the health of each individual cartridge in the library. This allows users to determine which cartridges should be left in service and which should be considered for removal. In addition to immediate feedback on cartridge health, users can periodically submit their collected data directly to Imation Technical Service via email and receive an annual analysis report on total library health and usage patterns. Imation can also provide a comparison of the customer library's usage pattern with industry trends. The patent pending algorithms utilized to determine cartridge status and comparisons to the industry are based on an Imation database of hundreds of thousands of cartridge scan records amassed globally. This additional analysis service allows the user to more accurately assess the condition of the library and predict future performance to minimize down time. Contact Imation Technical Service to arrange an advance report.

The Imation Secure Scan also provides an exciting security feature allowing users to lock cartridges for added data protection. This patent pending feature is useful when transporting or storing cartridges preventing the cartridge from functioning in any drive until it has been properly unlocked via the scanner with the user's password. This password is set by the user and can be changed when desired. In the unlikely event of a lost password, the customer can simply supply their encrypted key which is recorded with each locked cart operation. Imation can quickly reconstruct the customer password and supply it back to the customer via email to minimize any disruption.

## Start-up and Main Program Screen:

**NOTE:** For computer systems without physical serial communications ports, a delay of up to a minute or more may occur during program start-up. Please be patient while the software resolves virtual com port addressing.

The main program screen pictured below is where all major scanning and security functions are performed. The red letters will be used throughout this manual to point out various areas during the following discussion on software features and operation.

Customer Name: Jody  
Customer Location: Tech Service

Program Status:  
CM Reader: COM 7  
Barcode Scanner: COM 5  
Cart already in database

Session: Scan Only  
Scan Only  
Scan and Lock  
Scan and Unlock  
Show Lock/Unlock Status Only  
Lock Only  
Unlock Only

Start Session  
Stop Session  
Session Active  
Scan

Volser: S00579L2  
Cartridge Status: Good Cartridge, Unlocked

Scan Results:

Scan Date	Volser	Cart SN	Date/Mfg	Cart Mfg	Mounts	GB Wrt	GB Rd	Status
06/14/2010	S00579L2	0627752820	4/27/2004	IMATION	31	95	0	Good Cartridge
06/14/2010	D469033	0C85123110	11/30/2007	IMATION	0	0	0	New Cartridge
06/14/2010	R234567	0C77240140	9/6/2007	IMATION	1	166	0	Good Cartridge
06/14/2010	DB0047L3	05N1113992	11/6/2005	IMATION	48	1029	93	Good Cartridge
06/14/2010	DB0290L3	05N1114282	11/6/2005	IMATION	9	731	60	Good Cartridge
06/14/2010	B00230L2	0603407012	10/27/2006	IMATION	73	2663	1106	Good Cartridge

The Customer Name and Location fields (A) indicate who will be using the scanner and at what location. The default information shows a customer name of "Imation" and a customer location of "Oakdale". You will be prompted to change the defaults entering your own information on program start up. If you do not input your customer name and location information, the prompt is displayed each time the program is started until you do. This name and location can help to identify your data should you chose to upload it to Imation for further analysis in the future and help you manage data from multiple locations.

Customer Name: Imation  
Customer Location: Oakdale

Program Status:  
CM Reader: COM 7  
Barcode Scanner: COM 5

The Program Status Box (B) provides communications port connection information and the current condition of the CM (Cartridge Memory) chip reader and barcode reader. In addition, an information window will provide messages on the current state of the software or cartridge being scanned. The scanning progress bar is located directly beneath the Program Status Box and shows the progress of the scan in process.



The Session Selection Box (C) is where the desired operation for a given cartridge processing session is chosen. Use the radio button next to the desired operation to select it.



**Scan Only** - This selection causes the scanner to interrogate the cartridge memory chip and perform all standard analysis and scan data storing functions. No security operations are enabled. Note: Locked cartridges must be unlocked first before scanning.

**Scan and Lock** - This selection causes the scanner to interrogate the cartridge memory chip and perform all standard analysis and scan data storing functions. On the completion of the cartridge scan the cartridge is locked to prevent reading by any drive.

**Scan and Unlock** - This selection causes the scanner to unlock the cartridge allowing access by an appropriate LTO drive. After unlocking, the scanner interrogates the cartridge memory chip and performs all standard analysis and scan data storing functions.

**Show Lock/Unlock Status Only** - This selection checks and reports the lock status of the cartridge only and performs no other operations.

**Lock Only** - This selection locks the cartridge currently on the scanner preventing any drive from accessing the cartridge. No cartridge scan information is collected and no analysis is performed.

**Unlock Only** - This selection unlocks the cartridge currently on the scanner allowing it to be accessed by an appropriate LTO drive. No cartridge historical usage information is collected and no analysis is performed.




The **Start / Stop Session Buttons (D)** are used to initiate or stop an operating session. The Status information located immediately to the right of the buttons shows the type of session selected and whether the session is active or not.



The Volser Box (E) contains the volume serial number of the last successfully scanned tape.



The **Cartridge Status Box (F)** displays the disposition of the last successfully scanned cartridge and its lock status.



The scanning of a cartridge will result in one of six possible disposition messages in the cartridge status box as follows:

"New Cartridge"	The cartridge has had too little read / write use to determine its current condition or has been loaded < 4 times.
"Good Cartridge"	The cartridge passes all criteria and can remain in service.
"Analysis Recommended"	The cartridge has error performance issues or an invalid end of data mark and should be referred to the manufacturer for additional investigation.
"Warning: Exceeds Useful Life"	The cartridge has had > 5000 mounts or has excessive read / write activity during its life and should be retired. Cleaning cartridges will also be flagged with this message if they have exceeded the maximum recommended number of cleanings.
"Fail - Remove from Service"	The cartridge has had > 5000 mounts or has excessive read / write activity and has serious permanent errors and should be removed and retired.
"UCC - XX% Remaining Use"	Cleaning cartridges are identified when scanned and the remaining useful life is displayed as a percent of total. This is useful in ensuring that cleaning cartridges are not used past their intended life.

Note: Additional detail on each disposition message can be viewed by hovering the mouse pointer over the message in the cartridge status window as shown below.



**Cartridge Lock Operation:** The Imation Secure Scan has the capability to “Lock” a cartridge by processing the RFID chip using a patent pending method which once locked prevents the cartridge from being successfully loaded into an LTO drive. This feature is advantageous to the end user desiring additional security when storing or transporting LTO 1 through 5 media containing sensitive data.


To **lock** the cartridge, with no session active, select the desired lock option “Lock Only” or “Scan and Lock” from the Session Selection Box (C). Activate the scanning session and place the cartridge on the scanner to initiate the operation. Start the session and place a cartridge on the scanner. The Program Status Box (B) and Cartridge Status Box (F) will indicate the progress of the process. Repeat for each cartridge to be locked. Once locked, cartridges cannot be accessed by LTO drives.

To **unlock** the cartridges, select “Unlock Only” or “Scan and Unlock” in the Session Selection Box (C) as desired. Start the session and place a cartridge on the scanner. The Program Status Box (B) and Cartridge Status Box (F) will indicate the progress of the process. Repeat for each cartridge to be unlocked.

**During lock and unlock operations, it is extremely important that the user wait for the lock/unlock status message to be displayed on the screen and confirmation beep or tone BEFORE removing the cartridge from the scanner.**

A log file of all lock and unlock operations is retained and print controls for this file can be accessed via options in the Administrator menu described later in this manual.

In the event a password is lost, Imation can reconstruct your password for you by utilizing your encrypted key which is logged with each locked cartridge record. Contact Imation Technical Service for further assistance.



**Scan Results Table (G)**

Scan Date	Volser	Cart SN	Date/Mfg	Cart Mfg	Mounts	GB Wrt	GB Rd	Status
06/14/2010	S00579L2	0B27752820	4/27/2004	IMATION	31	95	0	Good Cartridge
06/14/2010	D469033	0C85123110	11/30/2007	IMATION	0	0	0	New Cartridge
06/14/2010	R234567	0C77240140	9/6/2007	IMATION	1	166	0	Good Cartridge
06/14/2010	DB0047L3	05N1113992	11/6/2005	IMATION	48	1029	93	Good Cartridge
06/14/2010	DB0290L3	05N1114282	11/6/2005	IMATION	9	731	60	Good Cartridge
06/14/2010	B00230L2	0603407012	10/27/2006	IMATION	73	2663	1106	Good Cartridge

This table is displayed on the lower half of the main program screen and contains a running display of the last 25 cartridges scanned with column definitions as follows:

**“Scan Date”** The day, month and year that the scan was performed.

**“Volser”** The volume serial number scanned from the barcode on the spine of the cartridge.

**“Cart SN”** The unique manufacturer’s cartridge serial number stored in the cartridge memory chip.

**“Date/Mfg”** The date on which the cartridge was manufactured.

**“Cart Mfg”** The listed manufacturer of the cartridge.

**“Mounts”** The count of load/unload cycles experienced by the cartridge to date.


**“GB Write”** The number of Gigabytes written to the cartridge since new.

**“GB Read”** The number of Gigabytes read from the cartridge since new.

**“Status”** The disposition of the cartridge based on the information scanned from the cartridge.

Cartridge data beyond the last 25 cartridges displayed in the scan results table can be viewed using the “Library Summary” screen described below.

**Windows Tool Bar “File” tab Selections (H)**



## Cartridge Library Summary Sub-screen Overview

This screen provides a summary and basic reporting for a customer selected set of cartridges.

**Library Summary**

Start Date: 04/21/2009 D  
End Date: 06/14/2010 D

**Collect Data**

Total Records: 66

**Record Shown**

- ☒ Good Cartridge
- ☒ New Cartridge
- ☒ Analysis Recommended
- ☒ Warning: Exceeds Useful Life
- ☒ Remove From Service
- ☒ Good Cleaning Cartridge

**Select All** **De-Select All**

**Cartridge Type Graph**  
**Cartridge Status Graph**  
**Cartridge Age Graph**  
**Cartridge Usage Graph**  
**Cartridge Mounts Graph**  
**Drives of Interest**

**Print List** **Export List**

**Cartridge Generations Shown**

- ☒ LTO1
- ☒ LTO2
- ☒ LTO3
- ☒ LTO4
- ☒ LTO5
- All**

Scan Date	Volser	Cart SN	Date / Mfg	Cart Mfg	Mount	GB-Wr	GB Rd	Status
04/08/2010	CLN001	036Q108888	7/4/2003	FUJIFILM	9	0	0	UCC- 83% Remaining Use
04/21/2009	B00088L2	039G108589	11/7/2003	FUJIFILM	406	52521	25946	Fail- Remove from Servic
04/21/2009	200558L2	0309100457	10/18/2003	FUJIFILM	297	1785	463	Good Cartridge
04/21/2009	200654L2	0309100974	10/18/2003	FUJIFILM	120	1459	234	Good Cartridge
04/21/2009	200517L2	030R110923	11/16/2003	FUJIFILM	175	1787	152	Good Cartridge
04/21/2009	005519L1	042J113676	2/28/2004	FUJIFILM	939	1100	293	Analysis Recommended
04/21/2009	200725L2	0469116153	6/23/2004	FUJIFILM	101	882	520	Good Cartridge
04/21/2009	200857L2	048A300139	10/28/2004	FUJIFILM	257	1184	1312	Good Cartridge
04/21/2009	RJ2926L2	04NP104399	12/4/2004	FUJIFILM	44	700	558	Good Cartridge
04/21/2009	DB0186L3	05N1102062	11/5/2005	FUJIFILM	89	651	101	Good Cartridge
04/21/2009	DB0297L3	05N1112479	11/6/2005	FUJIFILM	10	1012	386	Analysis Recommended
04/21/2009	DB0092L3	05N1113395	11/6/2005	FUJIFILM	113	689	255	Good Cartridge
04/21/2009	DB0047L3	05N1113992	11/6/2005	FUJIFILM	48	1029	93	Good Cartridge
04/21/2009	DB0007L3	05N1114076	11/6/2005	FUJIFILM	27	771	314	Analysis Recommended
04/21/2009	DB0290L3	05N1114282	11/6/2005	FUJIFILM	9	731	60	Good Cartridge
04/21/2009	REF004L4	062D402542	2/2/2006	FUJIFILM	2	132	132	Good Cartridge
04/21/2009	200621L2	066T409306	6/30/2006	FUJIFILM	30	259	0	Good Cartridge
04/21/2009	B00230L2	060J407012	10/27/2006	FUJIFILM	73	2663	1106	Good Cartridge
04/21/2009	B00211L2	060J407044	10/27/2006	FUJIFILM	57	2687	442	Good Cartridge
04/21/2009	B00201L2	060P408485	10/27/2006	FUJIFILM	68	2563	728	Good Cartridge
04/21/2009	B00226L2	060Q400019	10/27/2006	FUJIFILM	84	2684	956	Good Cartridge
04/21/2009	B00223L2	060Q401057	10/27/2006	FUJIFILM	59	2833	816	Good Cartridge
04/21/2009	001624L2	0783411683	8/8/2007	FUJIFILM	14	249	46	Analysis Recommended

### Start Date / End Date Data Boxes

Input the desired starting and ending dates for the scan data to be gathered. All scans within that range are gathered and reflected in the report. A pop up calendar button is provided to the right of the date window for convenience.

### Collect Data Button

Initiates the retrieval of information from the database.

### Record Shown Filter Selection

Select or deselect the check boxes to limit the data displayed by disposition type.

### Print and Export List Buttons

Allow the user to either print a hard copy or export a comma delimited text file for further manipulation.

### Cartridge Generation Selection

Filters the output to show only the cartridge type(s) selected.



## Cartridge List Data Table (at bottom of Library Summary screen)

Scan Date	Volser	Cart SN	Date / Mfg	Cart Mfg	Mount	GB-Wr	GB Rd	Status
06/14/2010	DB0047L3	05N1113992	11/6/2005	FUJIFILM	48	1029	93	Good Cartridge
06/14/2010	DB0290L3	05N1114282	11/6/2005	FUJIFILM	9	731	60	Good Cartridge
06/14/2010	B00230L2	060J407012	10/27/2006	FUJIFILM	73	2663	1106	Good Cartridge
06/14/2010	S00579L2	0B27752820	4/27/2004	IMATION	31	95	0	Good Cartridge
06/14/2010	R234567	0C77240140	9/6/2007	IMATION	1	166	0	Good Cartridge
06/14/2010	D469033	0C85123110	11/30/2007	IMATION	0	0	0	New Cartridge
05/13/2010	GG0200	0D02506930	8/28/2008	IMATION	9	503	0	Good Cartridge
05/13/2010	HH1136L3	0D12974310	1/6/2009	IMATION	11	503	2	Good Cartridge
05/13/2010	HH1135L3	0D15639230	1/25/2009	IMATION	1	438	0	Good Cartridge
05/13/2010	HH1131L3	0D18351780	2/24/2009	IMATION	1	503	0	Good Cartridge
05/13/2010	HH2126L3	0D20499160	3/18/2009	IMATION	0	0	0	New Cartridge
05/13/2010	HH2125L3	0D28386770	5/29/2009	IMATION	0	0	0	New Cartridge
05/13/2010	HH1137L3	0D30121210	6/20/2009	IMATION	3	503	0	Good Cartridge
05/13/2010	HH1937L3	0D31854000	7/30/2009	IMATION	1	503	0	Good Cartridge
05/13/2010	HH1173L3	0D31902700	7/31/2009	IMATION	1	503	0	Good Cartridge
05/13/2010	HH1836L3	0D31929650	7/31/2009	IMATION	0	0	0	New Cartridge
05/13/2010	HH1139L3	0D32071810	8/1/2009	IMATION	1	503	0	Good Cartridge
05/13/2010	HH1162L3	0D33059560	8/12/2009	IMATION	3	528	0	Good Cartridge
05/13/2010	HH1182L3	0D33131730	8/12/2009	IMATION	1	466	0	Good Cartridge
05/13/2010	HH1193L3	0D33134300	8/12/2009	IMATION	1	503	0	Good Cartridge
05/13/2010	HH1183L3	0D33134350	8/12/2009	IMATION	2	503	503	Good Cartridge
05/13/2010	HH1936L3	0D33140330	8/12/2009	IMATION	1	503	0	Good Cartridge
05/13/2010	HH1935L3	0D33150520	8/12/2009	IMATION	3	503	0	Good Cartridge

**“Scan Date”** The day, month and year that the scan was performed.

**“Volser”** The volume serial number scanned from the barcode on the spine of the cartridge.

**“Cart SN”** The unique manufacturer's cartridge serial number stored in the cartridge memory chip.

**“Date/Mfg”** The date on which the cartridge was manufactured.

**“Cart Mfg”** The manufacturer of the cartridge.

**“Mounts”** The count of load/unload cycles experienced by the cartridge to date.


**“GB Write”** The number of Gigabytes written to the cartridge since new.

**“GB Read”** The number of Gigabytes read from the cartridge since new.


**“Status”** The disposition of the cartridge based on the information scanned from the cartridge.

**Note:** Columns can be sorted in ascending or descending order by clicking on the column heading.


Graph selection buttons:




**Cartridge Type Graph** - Provides a color coded pie chart depicting the make up of the library by cartridge generation (LTO 1 through 5). Each cartridge type is shown in the industry standard color accepted for that LTO cartridge generation.




**Cartridge Status Graph** - Displays a pie chart showing the relative relationship between the various cartridge dispositions across the library. Each disposition is color coded to match that which is used on the main program screen.




**Cartridge Age Graph** - Provides a histogram of the age (in months) of the cartridges included within the dates specified.



**Cartridge Usage Graph** - Provides a histogram of the amount of data written and read from the carts in the collection set.




**Cartridge Mounts Graph** - Provides a histogram of the number of mounts (drive load/unload cycles) for the cartridges in the collected data set.






**Drives of Interest Graph** - Provides a display of drive serial numbers highlighting those which have been calculated to be statistically different than the total drive population. This distinction may indicate that a drive requires maintenance attention. This information can be used to help the customer and their hardware support professional manage the drives in use in the library. The total good carts accessed by each drive is shown in Blue, Cartridges which experience errors are shown in Yellow, and any drives of statistical interest are displayed in Red.



### Volser Summary Screen Selection



**Volser Summary Screen Overview** The Volser summary screen provides the user with a method to review the scan history of a particular cartridge of interest displaying all records on file in table form.

Scan Date	Cart SN	Mounts	GB Wrt	GB Rd	Drv Mfg	Last Drive	Status
01/30/2009	0C66836270	6	26	0	HP	HU10530GUR	
01/30/2009	0C66836270	7	26	0	HP	HU105251YC	
01/30/2009	0C66836270	8	104	0	HP	HU105251YC	
01/30/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/02/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/02/2009	0C66836270	7	26	0	HP	HU105251YC	
02/02/2009	0C66836270	8	104	0	HP	HU105251YC	
02/02/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/03/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/03/2009	0C66836270	7	26	0	HP	HU105251YC	
02/03/2009	0C66836270	8	104	0	HP	HU105251YC	
02/03/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/04/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/04/2009	0C66836270	7	26	0	HP	HU105251YC	
02/04/2009	0C66836270	8	104	0	HP	HU105251YC	
02/04/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/05/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/05/2009	0C66836270	7	26	0	HP	HU105251YC	
02/05/2009	0C66836270	8	104	0	HP	HU105251YC	
02/05/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/12/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/12/2009	0C66836270	7	26	0	HP	HU105251YC	
02/12/2009	0C66836270	8	104	0	HP	HU105251YC	
02/12/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/13/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/13/2009	0C66836270	7	26	0	HP	HU105251YC	
02/13/2009	0C66836270	8	104	0	HP	HU105251YC	

#### Volser Entry Box & Scan Volser Button

You can place the cartridge on the scanner and click the “Scan Barcode” button to obtain the volser from the cartridge or type it in manually into the volser box. When using the scanner to obtain the volser, please ensure that a cartridge is in place on the Imation Secure Scan fixture before clicking on the “Scan Barcode” button to prevent inadvertent laser exposure

#### Collect Data Button

With the barcode scanned or entered, click to collect information on the cartridge in question.

### Entries Found info box

Indicates the number of times a cartridge chip has been scanned by the Imation Secure Scan. The LTO cartridge memory chip contains information on the last four drive mounts the cartridge has experienced. Each time a cartridge is scanned by the Secure Scan, the current condition of the cartridge is determined. In addition, the information on the previous 3 mounts is stored, resulting in up to 4 sets of information for each time the cartridge is scanned on the Secure Scan. For Example, 10 scans of the cartridge below results in data on as many as 40 drive mount events for that cartridge.

### Print and Export Buttons

Allows the user to either print a hard copy of the data or export a comma delimited text file (csv) for further manipulation

### Volser Summary Data Table

Scan Date	Cart SN	Mounts	GB Wrt	GB Rd	Drv Mfg	Last Drive	Status
01/30/2009	0C66836270	6	26	0	HP	HU10530GUR	
01/30/2009	0C66836270	7	26	0	HP	HU105251YC	
01/30/2009	0C66836270	8	104	0	HP	HU105251YC	
01/30/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/02/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/02/2009	0C66836270	7	26	0	HP	HU105251YC	
02/02/2009	0C66836270	8	104	0	HP	HU105251YC	
02/02/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/03/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/03/2009	0C66836270	7	26	0	HP	HU105251YC	
02/03/2009	0C66836270	8	104	0	HP	HU105251YC	
02/03/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/04/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/04/2009	0C66836270	7	26	0	HP	HU105251YC	
02/04/2009	0C66836270	8	104	0	HP	HU105251YC	
02/04/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/05/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/05/2009	0C66836270	7	26	0	HP	HU105251YC	
02/05/2009	0C66836270	8	104	0	HP	HU105251YC	
02/05/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/12/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/12/2009	0C66836270	7	26	0	HP	HU105251YC	
02/12/2009	0C66836270	8	104	0	HP	HU105251YC	
02/12/2009	0C66836270	9	104	0	HP	HU10530GV5	Good Cartridge
02/13/2009	0C66836270	6	26	0	HP	HU10530GUR	
02/13/2009	0C66836270	7	26	0	HP	HU105251YC	
02/13/2009	0C66836270	8	104	0	HP	HU105251YC	

**Scan Date** Is simply the date that the cartridge information was gathered.

**Cart SN** The internal cartridge serial number.

**Mounts** The number of load / unload cycles recorded for that cartridge

**GB Wr** The total Gigabytes of data written to the cartridge during it's service life.

**GB Rd** The total Gigabytes of data read from the cartridge during it's service life.

**Drive Mfg** The manufacturer of the last drive used to write information to the cartridge memory chip.

**Last Drive** The serial number of the last drive that the cartridge was loaded into.

**Status** The result of the last completed cartridge scan.


### Upload to Imation Overview

This function allows the user to send in a data file containing the library usage information collected so that more in depth analysis can be provided by Imation Technical Service. **ONLY CARTRIDGE USE INFORMATION IS SENT.** Because the Imation Secure Scan **DOES NOT** access the actual magnetic tape in the cartridge, no customer data is involved. By partnering with Imation Technical Service, very detailed reports can be provided assisting you in management of your library to maximize media usage and life, and minimize down time by identifying potential media volume and drive hardware issues.



### E-Mail Entry field

This dialog box allows the user to enter additional email addresses to which the application will mail usage data.





**Send E-mail** - Once additional email addresses have been entered, click this button to initiate the upload. Records are gathered and a file sent to Imation Technical Service as well as any additional addresses entered via the window described above. An E-mail Progress window (shown below) will indicate the operation's status by showing the number of records being processed.



Once the file has been compiled and the e-mail sent, the following "Upload Complete!!!" message will be displayed.



**Generate Files for Manual Send** - If there are overlying security or other concerns, the user may elect to send files to Imation by manually attaching the files to an e-mail. Selecting this button generates that file and places it in the program directory. If the default location was used when installing the software, the export file will be found in: "**C:\Program Files\Imation Secure Scan\**". The file is named "CustomerDB.mdb" The file size is limited to 10MB to prevent issues while emailing. If your file size exceeds that limit, contact Imation Technical Service for further instructions.

### Administrator options - Overview:


This menu allows an administrator to access various software managerial functions. Functional descriptions are outlined below for each option.



**Enter Admin Mode:** In order to access the administrative functions the user must enter a password. The default password is "imation" (lower case) and is entered in via the text box shown below:




**Set Admin Password:** The designated administrator should change the default password in order to protect sensitive software settings and ensure security for locking functions. The administrator password is used to both gain entry into the administrative functions and to lock cartridges.



**Enter License Key:** This function allows the entry of a license key for locking cartridges. Each key validates locking privileges for one calendar year. Multiple license keys can be added in succession. Each additional key adds an additional year to the lock and data upload feature's expiration date. Contact your Imation sales representative for information on obtaining keys. Note: this key may be subject to periodic renewal fees.



**Customize Name and Location:** This input box allows the user to enter their desired customer name and location information. These labels are used for identifying the source of scan data both to users with multiple Imation Secure Scan units and also to Imation should advanced reporting or assistance be desired. **The name and location must be changed from the default values.** This window will display each time the software starts up until they are modified by the administrator.



A screenshot of a 'Customization' dialog box. The title bar is blue with a red 'i' icon and a close button. The main area has a light beige background. It contains two text input fields: 'Customer Name' with the text 'Lab' and 'Customer Location' with the text 'Oakdale'. Below the fields are two buttons: 'OK' and 'Cancel'.

**Lock/Unlock Enable:** These two options control the availability of the cartridge lock and unlock functions while on the main operating screen.






**Lock/Unlock Log Print Enable:** This check item controls whether the user will be prompted for printing of log files for lock/unlock functions at the end of each scanning session. A log file is always retained regardless of print status.



**Extended Export Data:** This option selects the level of detail supplied via the export data function under the Library Summary screen. When selected, additional performance detail is supplied for advanced users.



**Set Alternate Email Server:** This option allows the user to specify an alternative internal email server. This may be necessary if your corporate firewalls or other data security measures cause difficulty with the "Email to Imation" function.



**Exit Admin Mode:** This selection exits from the administration menu and disables access to the administration functions until reentry of the administrator password.



## Regulatory Compliance



### EMC

FCC ID: PB4ISS-LTOA (for Ver. 1, SN beginning with A001)

Contains FCC ID OKY1003925351A02C (for Ver. 2, SN beginning with A101)

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

IC: 6900A-ISSLTOA (for Ver. 1, SN beginning with A001)

Contains IC 7657A-10039253 (for Ver. 2, SN beginning with A101)

The term "IC:" before the equipment certification number only signifies that the Industry Canada technical specifications were met.


Thailand: This telecommunication equipment conforms to NTC technical requirement.

Singapore: Complies with IDA Standards, Dealer's License No. DA104910

Indonesia Certificate No. 13623, PLG. ID: 3157

Philippines: NTC Type Approval No.: ESD-1004468C

China: SRRC CMII ID 2011DJ5335

Taiwan:  CCXXxxYYyyyZzW

Australia New Zealand:  N477

### Product Safety

Conforms to UL Std 60950-1

Certified to CAN/CSA Std C22.2 No. 60950-1

### Laser Safety

CLASS 1 LASER PRODUCT

As tested to IEC 60825-1: 2007 and 21 CFR 1040.10

**CAUTION:** Class 2 laser radiation when open. Do not stare into the beam.

**AVERTISSEMENT:** Rayonnement laser de catégorie 2 lorsque l'appareil est allumé. Éviter de regarder le faisceau lumineux.

**Caution** - Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

### Environmental

**WEEE:** Product is registered and labeled as not appropriate for common disposal.

**RoHS:** All materials and processes used in the system meet the limits for compliance.

### Specifications

Voltage Requirement . . . . .5VDC through USB

Current. . . . .450mA

Power. . . . .2.25 watts

RF Frequency. . . . .13.56 MHz

Barcode scanner wavelength . . . .650nm

Max. Laser Power. . . . .<0.39mW

Communication Interface. . . . .Dual USB-A

Operating Environment . . . . .10° to 30°C / 20 to 60% RH

Dimensions (scanner). . . . .5.59"L x 5.64"W x 2.44"H (142 x 143 x 62mm)

Dimensions (scanner with case). . .14.2"L x 11.4"W x 6.5"H (360 x 290 x 165mm)

Weight (scanner) . . . . .0.70 lbs. (0.32kg)

Weight (scanner with case) . . . . .5.65 lbs. (2.56kg)

Assembled in US with non-US and US components

Multiple Patents Pending

### Warranty

LIMITED WARRANTY AND LIMITATION OF REMEDIES\*: Imation warrants that this product is free from defects in material and manufacture at the time of purchase. If any such defect appears within 1 year, Imation's entire liability is, at Imation's option, either (a) repair, or (b) replacement of the product, or (c) refund of the purchase price of the product, which must be returned to Imation with proof of purchase. This warranty does not apply to product failure resulting from misuse, abuse, accident, neglect or mishandling, improperly adjusted or maintained drives, incorrect environments or wear from ordinary use. IMATION SHALL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL LOSS OR DAMAGE (INCLUDING WITHOUT LIMITATION DAMAGES FOR LOSS OF PROFITS, SAVINGS OR DATA) IN ANY WAY RELATED TO THE PRODUCT. This does not preclude claims for personal injury. Some states or countries do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or country to country.

### Technical Support

For further assistance with the Imation Secure Scan, please contact Imation Technical Support at 1-800-351-8186 and select option 1, or navigate to [www.imation.com](http://www.imation.com) and click on "support".

Imation Enterprises Corp.  
1 Imation Way  
Oakdale, MN 55128-3414 U.S.A.

[www.imation.com](http://www.imation.com)

Imation and the Imation logo are trademarks of Imation Corp.  
All other trademarks are the property of their respective owners.

6695 0780-C